Instruction Manual

StarTech.com

Hard-to-find **made easy** ®

6 ft. USB to DB25 Parallel Printer Adapter Cable

ICUSB1284D25

DE: Bedienungsanleitung - de.startech.com
FR: Guide de l'utilisateur - fr.startech.com
ES: Guía del usuario - es.startech.com
IT: Guida per l'uso - it.startech.com
NL: Gebruiksaanwijzing - nl.startech.com
PT: Guia do usuário - pt.startech.com

Packaging Contents

• 1 x USB to Parallel Printer Cable

System Requirements

• Intel-compatible 486DX-66 MHz CPU or higher with an available USB port
• Windows® 8 (32/64bit), 7 (32/64), Vista (32/64), XP(32/64), 2000, ME, 98SE; Windows® Server 2008 R2; Mac OS 10.0 – 10.8; Linux 2.6.x – 3.9.x

*actual product may vary from photos

Installation

Windows / Mac OS
NOTE: Installation on a computer that is running Windows 2000 and later), or Mac OS 10.4 (and later) is automatic
1. Connect the USB to Parallel cable to an available USB port - do not connect the printer to the cable yet.
2. The OS will detect the cable and install the necessary software automatically.

Windows 98SE
1. Open a web browser and go to www.startech.com/downloads.
2. Enter the product ID "ICUSB1284D25" and click Search.
3. Select the product from the search results, and download the available Prolific_PL2305.zip file.
4. Once downloaded, extract the contents using your preferred utility.
5. Connect the USB to Parallel cable to an available USB port - do not connect the printer to the cable yet.
6. Windows will detect the adapter and prompt for drivers.
7. Browse to the location that the download was saved and select the "Prolific_PL2305.zip\MS_pl2305_Win98" folder as the location to search for drivers.
8. Windows will automatically install the drivers from the download.

Setting Up a Printer Device

1. Turn off your printer. Plug the DB25 connector of the USB to Parallel Printer cable into your printer or printer cable.
2. Turn your printer and computer on.
3. Plug the USB connector of the cable into the USB port of your computer.
4. If you have already installed a printer device before click "Start", "Settings", "Printers". Right-click the default installed printer and click on "Properties". The properties dialog box of the installed printer will appear on your screen.
5. Click the details folder tab and change the printer port to LPT2:USB to Parallel Port (Win98SE) or USB001 (WinXP *Note that there may be other USB00x ports, so you may need to try each one).
6. If you do not have a printer installed yet, click "Start", "Settings", "Printers", "Add Printer". The Add Printer Wizard will start and assist you in installing a new printer device. Select the printer manufacturer and model name from the list provided by the wizard or use the driver disk supplied with your printer.
7. When prompted which port the printer will use, click on LPT2:USB to Parallel Port (Win98SE) or USB001 (WinXP *Note that there may be other USB00x ports, so you may need to try each one).

![StarTech.com logo - Hard-to-find made easy®]

Specifications

Bus Interface	USB 1.x
Connectors	1 x USB type A male 1 x 25-pin D-Sub (DB25) female
Maximum Data Transfer Rate	1.5Mbps
Power Adapter	USB powered
Operating Temperature	5°C ~ 40°C (41°F ~140°F)
Storage Temperature	-20°C ~ 70°C (-4°F ~ 158°F)
Humidity	0% ~ 80% RH
Cable Length	1.8m / 6ft
Operating System Support	Windows® 8 (32/64bit), 7 (32/64), Vista (32/64), XP(32/64), 2000, ME, 98SE Windows® Server 2008 R2 Mac OS 10.0 – 10.8 Linux 2.6.x – 3.9.x