

Nola Cantilever ASSEMBLY INSTRUCTION

<p>1</p>			<p>3</p>			
<p>2</p> <p>Please insert and tighten all the screws for armrests firstly ,then insert the plastic cap .</p>						
① CANTI BASE	② BACK&SEAT CUSHION	③ ARMREST	④ SCREW	⑤ SCREW	⑥ ALLEN KEY	⑦ ALLEN KEY
			M8*14	M8*40	M5	M6
1 PC	1 PC	1 PAIR	4 PCS	4 PCS	1 PC	1 PC

IMPORTANT NOTE - PLEASE ASSES ALL COMPONENTS PRIOR TO DISPOSAL OF PACKAGING AND ASSEMBLY OF CHAIR