

PORTLAND3 ASSEMBLY INSTRUCTION

<p>1</p>	<p>3</p> <p>take the backrest and remove the black clip which holds the ratchet mechanism in place</p>	<p>5</p>						
<p>2</p>	<p>4</p> <p>Insert the backrest into the ratchet mechanism attached to the seat. Insert the ratchet mechanism into the narrow end and the backrest plate into the wider end</p>							
<p>① CASTOR</p>	<p>② 5-STAR BASE</p>	<p>③ GAS LIFT</p>	<p>④ SEAT CUSHION</p>	<p>⑤ BACK CUSHION</p>	<p>⑥ ARMREST</p>	<p>⑦ SCREW M6*40</p>	<p>⑧ ALLEN KEY</p>	<p>⑨ BELLOW COVER</p>
<p>5 PCS</p>	<p>1 PC</p>	<p>1 PC</p>	<p>1 PC</p>	<p>1 PC</p>	<p>1 PAIR</p>	<p>6 PCS</p>	<p>1 PC</p>	<p>1 PC</p>

IMPORTANT NOTE - PLEASE ASSES ALL COMPONENTS PRIOR TO DISPOSAL OF PACKAGING AND ASSEMBLY OF CHAIR