

ST204(T312) ASSEMBLY INSTRUCTION

<p>1</p>	<p>3</p>	<p>4</p>			
<p>2</p>	<p>① CASTOR</p> <p>5 PCS</p>	<p>② 5-STAR BASE</p> <p>1 PC</p>			
<p>③ GAS LIFT</p> <p>1 PC</p>	<p>④ DUST COVER</p> <p>1 PC</p>	<p>⑤ SEAT CUSHION</p> <p>1 PC</p>	<p>⑥ BACK CUSHION</p> <p>1 PC</p>	<p>⑦ BELLOWS COVER</p> <p>1 PC</p>	