


www.teknikoffice.co.uk

Teknik



Guaranteed to **hold**
other **beverages**, too.


Hampstead Park Lift Up Table

Model 5426504


Table of Contents

Assembly Tools Required


Part Identification	3
Hardware Identification	4
Assembly Steps	5-19



No. 2 Phillips Screwdriver
Tip Shown Actual Size




Adjustable Wrench



Tape Measure


Part Identification

Now you know
our ABCs.



† While not all parts are labeled, some of the parts will have a label or an inked letter on the edge to help distinguish similar parts from each other. Use this part identification to help identify similar parts.

A	RIGHT END (1)	D	LOUVERED PANEL (2)	G	BASE (2)
B	LEFT END (1)	E	SHELF (1)	H	TOP (1)
C	STRETCHER (1)	F	UPRIGHT (1)	J	BOTTOM (1)




Hardware Identification

† Screws are shown actual size. You may receive extra hardware with your unit.


1F HIDDEN CAM - 18




2F CAM DOWEL - 12




8F CAM SCREW - 6




15F WOOD DOWEL - 4



4G METAL BRACKET - 10




37G SUPPORT BRACKET - 2



2M BUMPER - 4




13M BLACK WASHER - 8



24M NUT - 8



74M LIFT TABLE MECHANISM SET - 1




80M SILVER WASHER - 2




91M BUSHING - 2




1S BLACK 9/16" LARGE HEAD SCREW - 36




52S SILVER 3/4" PAN HEAD SCREW - 2



92S BLACK 3/4" MACHINE SCREW - 4



93S BLACK 1-1/4" MACHINE SCREW - 4




113S BLACK 1-15/16" FLAT HEAD SCREW - 4




Hardware Usage Guide

HOW TO USE A HIDDEN CAM & CAM DOWEL



2. Insert the metal end of the CAM DOWEL into the HIDDEN CAM.




1. Push a HIDDEN CAM into the part. The arrow in the HIDDEN CAM must point toward the hole in the edge of the board.

3. **Caution**

Risk of damage or injury. HIDDEN CAMS must be completely tightened. HIDDEN CAMS that are not completely tightened may loosen, and parts may separate. To completely tighten:


Start




Tighten

Maximum 210 degrees


Minimum 190 degrees



HOW TO USE A HIDDEN CAM & CAM SCREW




1. Turn the CAM SCREW until the shoulder is against the surface of the part.




2.

Push a HIDDEN CAM into the part. The arrow in the HIDDEN CAM must point toward the hole in the edge of the board.



3.


Insert the CAM SCREW into the HIDDEN CAM. Tighten the HIDDEN CAM.



Step 1


- ✚ Assemble your unit on a carpeted floor or on the empty carton to avoid scratching your unit or the floor.
- ✚ Push four HIDDEN CAMS (1F) into the short edges of the SHELF (E). Then, insert the metal end of a CAM DOWEL (2F) into each HIDDEN CAM.
- ✚ Push six HIDDEN CAMS (1F) into the long edges of the SHELF (E).

Do not tighten the HIDDEN CAMS in this step.




Step 2

- ✦ Push four HIDDEN CAMS (1F) into the LOUVERED PANELS (D). Then, insert the metal end of a CAM DOWEL (2F) into each HIDDEN CAM.
- ✦ Turn six CAM SCREWS (8F) into the LOUVERED PANELS (D).
- ✦ Fasten the LOUVERED PANELS (D) to the SHELF (E). Tighten six HIDDEN CAMS.




Step 3

- Fasten the UPRIGHT (F) to the SHELF (E). Use two BLACK 1-15/16" FLAT HEAD SCREWS (113S).




Step 4

- Push four HIDDEN CAMS (1F) into the BOTTOM (J). Then, insert the metal end of a CAM DOWEL (2F) into each HIDDEN CAM.




Step 5

- ✚ Fasten ten METAL BRACKETS (4G) to the BASES (G). Use ten BLACK 9/16" LARGE HEAD SCREWS (1S).
- ✚ **NOTE:** Be sure the BRACKETS are even with the edges of the BASES.
- ✚ Fasten the BASES (G) to the BOTTOM (J). Use six BLACK 9/16" LARGE HEAD SCREWS (1S).




Step 6

- Fasten the BOTTOM (J) to the UPRIGHT (F). Use two BLACK 1-15/16" FLAT HEAD SCREWS (113S).




Step 7

- ✚ Insert four WOOD DOWELS (15F) into the short edges of the LOUVERED PANELS (D).
- ✚ Fasten the ENDS (A and B) to the LOUVERED PANELS (D), SHELF (E), and BOTTOM (J). Tighten twelve HIDDEN CAMS.
- ✚ **NOTE:** Be sure the WOOD DOWELS in the LOUVERED PANELS insert into the ENDS.
- ✚ Fasten the BASES (G) to the ENDS (A and B). Use four BLACK 9/16" LARGE HEAD SCREWS (1S).





Step 8

- ⚡ Carefully stand your unit upright.
- ⚡ Push four BUMPERS (2M) into the top edges of the ENDS (A and B).



Step 9


- 1st Fasten the front edge of the LIFT TABLE MECHANISM (74M) to the TOP (H) as shown. Use two BLACK 9/16" LARGE HEAD SCREWS (1S).
- IMPORTANT:** You will need a tape measure to be sure the holes in the TOP (H) are the correct distance from the long edges as shown.
- 2nd Press the LIFT TABLE MECHANISM (74M) down to access the back hole.
- 3rd Fasten the back edge of the LIFT TABLE MECHANISM (74M) to the TOP (H). Use a BLACK 9/16" LARGE HEAD SCREW (1S).
- Repeat this step for the other LIFT TABLE MECHANISM as shown.



Step 10

Fasten the SUPPORT BRACKETS (37G) to the LIFT TABLE MECHANISMS (74M). Use four BLACK WASHERS (13M), four NUTS (24M), and four BLACK 3/4" MACHINE SCREWS (92S).



NOTE: Position the SUPPORT BRACKETS exactly as shown.



Step 11

- ✚ **IMPORTANT:** You will need someone's help in this step.
- ✚ Fasten the LIFT TOP MECHANISMS (74M) to the ENDS (A and B). Use ten BLACK 9/16" LARGE HEAD SCREWS (1S) through the LIFT TABLE MECHANISMS (74M) and into the holes in the ENDS as shown in the enlarged diagram.


✚ **NOTE:** Be careful when lining up the holes in the MECHANISMS with the holes in the ENDS as to not damage any parts. You should start each SCREW a few turns before completely tightening any of them.



Step 12

- Fasten the BUSHINGS (91M) to the ENDS (A and B). Use two BLACK 3/4" PAN HEAD SCREWS (85S) through the BUSHINGS, through two SILVER WASHERS (80M), through the LIFT TABLE MECHANISMS (74M), and into the ENDS.


NOTE: Do not overtighten the SCREWS.



Step 13


Fasten the STRETCHER (C) to the SUPPORT BRACKETS (37G) on the LIFT TABLE MECHANISMS (74M). Use four BLACK WASHERS (13M), four NUTS (24M), and four BLACK 1-1/4" MACHINE SCREWS (93S).

NOTE: Use an Adjustable Wrench and a Phillips Screwdriver in this step.



Step 14

- ✚ **IMPORTANT:** Do not place valuables in the storage space.
- ✚ **NOTE:** Please read the back pages of the instruction booklet for important safety information.
- ✚ This completes assembly. Clean with a damp cloth. Wipe dry.



⚠ WARNING

Please use your furniture correctly and safely. Improper use can cause safety hazards, or damage to your furniture or household items. ***Carefully read the following chart.***

Look out for:	What can happen:	How to avoid the problem:
<ul style="list-style-type: none">• Overloaded shelves.	<ul style="list-style-type: none">• Risk of injury.• Top-heavy furniture can tip over.• Overloaded shelves can break.	<ul style="list-style-type: none">• Never exceed the weight limits shown in the instructions.• Work from bottom to top when loading shelves. Place the heavier items on the lower shelves.
<ul style="list-style-type: none">• Placing TVs on furniture items that are not designed to support a television is hazardous.	<ul style="list-style-type: none">• Risk of injury or death. TVs can be very heavy. Plus the weight and location of the picture tube tends to make TVs unbalanced and prone to tipping forward.	<ul style="list-style-type: none">• This product is not designed to support a television.